



**WARNING:**  
CHOKING HAZARD - SMALL PARTS.  
NOT FOR CHILDREN UNDER 3 YEARS.

## 1 What is Chibibotto?



Chibibotto is a chubby, funny little robot who likes to play with you. He cannot speak, but can express himself by eye expressions, wiggling his arms, and making sounds. He plays robotic tunes by himself, and sometimes sings according to his mood. And he likes to be tapped!

Chibibotto changes into 20 characters. Besides those 20 characters, Chibibotto also has dozens more expressions that temporarily appear on the screen.

He has happy, angry, and funny expressions. Sometimes he sings, sometimes he is angry, and if you leave him for a long time, he closes the shutter and falls asleep.

How do you play with Chibibotto?

## 2 A Look at Chibibotto



### Before you play:

- Pull out the battery insulation tab;
- Insert AAA battery (please see below. "Inserting the Batteries");
- Push re-set button at back of the toy (Beep sound);

Chibibotto will now wake up and do a little show for you!




## 3 How to Play

Please tap Chibibotto lightly with a pen. When Chibibotto is tapped, his eye expression will show .

Do not tap Chibibotto too roughly, or you may damage the product.

### Tapping!

Tapping Chibibotto can suddenly change his mood or make him get angry. If you tap him too much, he may become unconscious! Gently tap him once, then wait a bit. He will soon recover and go back to normal.



## 4 How to Set the Clock

Please set the clock before play.

- Change to Clock mode by pressing A or B until you see the clock.
- Push and hold the B button until LCD shows clock and alarm icons.
- Push B button to choose clock icon and push A button to set.
- Push B button to choose 'hour' and push A button to set.
- Push B button to choose 'minutes' and push A button to set.

## 5 How to Set the Alarm

- Change to Clock mode by pressing A or B until you see the clock.
- Push and hold B button until LCD shows clock and alarm icons.

- Push B button to choose alarm icon and push A button to set.
- Push B button to choose ON/OFF and push A button to set. (The alarm must be ON or it will not be set.)
- Push B button to choose 'hour' and push A button to set.
- Push B button to choose 'minute' and choose B button to set.
- When the alarm goes off, you can make it stop by tapping Chibibotto or pressing the A or B button.
- Alarm sound will automatically shut off after 30 seconds.

## 6 Things to Do with Chibibotto

### Slot Machine

Tap Chibibotto 3 times to bring up the Slot Machine. Tap him once to choose one eye and again to choose the other eye. Try to match up both eyes or you will get a funny looking face!

### Expression for certain times

Chibibotto has special eye expressions that appear at certain secret times. Watch Chibibotto carefully and check his face whenever you have time-you may catch him making some secret expressions!

### Sleeping

If you do not play with Chibibotto for a while, he will eventually close the curtains and go to sleep. Tap Chibibotto once to raise the curtain and wake him up.

### Selecting New Characters

You can change characters types everyday. Chibibotto will give you two choices every morning. Select one by tapping him.

## 7 Secret Codes

Chibibotto can also be played by using secret codes. All characters and events that appear in Chibibotto can be called by those secret codes-if you know them!

The secret codes are shown by different shapes. Each shape corresponds to a different way of tapping Chibibotto.

SHAPE	TAP	SHAPE	TAP
	XOO		OXO
	XXX		XXO
	XOX		OXX

To enter a code, you first have to get Chibibotto ready to listen to the code. Tap Chibibotto two times and his expression will change to P P



Now you can try to enter the codes! It takes some practice to learn to tap with the right rhythm so that Chibibotto will respond.

## 8 Sample Secret Codes

Here are a few secret codes to get you started. Each of these codes will change Chibibotto's character:

	Character A:				
	Character B:				
	Character C:				
	Character D:				
	Character E:				

You can also try these codes to get some temporary expressions:

	Sun glasses:				
	Double Hearts:				
	Tornado:				
	Ring Ring Phone:				

Example:

For example, if you would like to see Chibibotto with Sunglasses, the code is - or XXX XXO XXX XXO. So:

Tap five times, stop (pause), tap five times. If you have the rhythm just right, wait for 3 seconds and you will see Chibibotto with his Sunglasses!

There are many other secret codes! Sometimes Chibibotto gives you a hint for more secret codes. Those codes are not shown in this instruction sheet—you can only discover them by watching Chibibotto carefully. Write them down and share them with your friends!

## 9 Sound and Sensor ON and OFF

Chibibotto can be very active, and sometimes you need a break! You can turn off the speaker and the tapping sensor by following these steps:

- Switch to Robot Mode by pressing A or B until you can see Chibibotto's eyes.
- Push and hold the A button until it beeps. The sound is now OFF.
- Push and hold the A button again to turn sensor OFF.
- Push and hold the A button again to turn sound and sensor ON.

## 10 Inserting The Batteries

To insert the batteries, have an adult open the battery compartment cover at the back of the game. (Remove the screw holding the battery door onto the back of the game unit and remove the door.) Insert 4xAAA OR LR03 Batteries (Batteries not included) and 1xCR2032 (Batteries included) or equivalent as shown.




TO ENSURE PROPER FUNCTION :

- DO NOT MIX OLD AND NEW BATTERIES.
- DO NOT MIX ALKALINE STANDARD OR RECHARGEABLE BATTERIES.
- BATTERY INSTALLATION SHOULD BE DONE BY AN ADULT.
- NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED.
- RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED (IF REMOVABLE).
- RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION (IF REMOVABLE).
- ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
- BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY.
- EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.
- THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.

RESET BUTTON:

After battery insertion, the RESET switch may be pushed only if the game doesn't work properly. (Use a ball-point pen.) The display should appear as shown in the diagram at the right.



## 11 Caution/Defect or Damage



High temperature will destroy the unit. Do not leave unit in direct sunlight.



Do not use a pencil or pin to press the RESET switch. Use a ball-point pen.



Do not press the liquid crystal display and avoid heavy shock or the display may fail.



Clean only with a piece of soft dry cloth.

Replace battery at the first sign of erratic operation.

If a part of your CHIBIBOTTO is damaged or something has been left out, DO NOT RETURN THE GAME TO THE STORE. The store doesn't have replacement parts. Instead, write to us at:

Tiger Electronics, Ltd. Repair Center  
980 Woodlands Parkway  
Vernon Hills, Illinois 60061, U.S.A.

Please include a note with your return explaining the problem along with a sales slip, date, place of purchase and price paid. We will do our best to expedite your return promptly.

## 12 90-Day Limited Warranty

Tiger Electronics, Ltd. (Tiger) warrants to the original consumer purchaser of this product that the product will be free from defects in materials or workmanship for 90 days from the date of original purchase. This warranty does not cover damages resulting from accident, negligence, improper service or use or other causes not arising out of defects in materials or workmanship.

During this 90-day warranty period, the product will either be repaired or replaced (at Tiger's option) without charge to the purchaser, when returned with proof of the date of purchase to either the dealer or to Tiger.

Product returned to Tiger without proof of the date of purchase or after the 90-day warranty period has expired, but prior to one year from the original date of purchase, will be repaired or replaced (at Tiger's option) for a service fee of U.S.\$9.50. Payments must be by check or money order payable to Tiger Electronics, Ltd.

The foregoing states the purchaser's sole and exclusive remedy for any breach of warranty with respect to the product.

All product returned must be shipped prepaid and insured for loss or damage to:

Tiger Electronics, Ltd. Repair Dept.  
980 Woodlands Parkway  
Vernon Hills, Illinois 60061, U.S.A.

The product should be carefully packed in the original box or other packing materials sufficient to avoid damage during shipment. Include a complete written description of the defect, a check if product is beyond the 90-day warranty period, and your printed name, address and telephone number.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE TIGER IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NINETY (90) DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT.

Some states do not allow limitations as to how long an implied warranty lasts and/or exclusions or limitations of incidental or consequential damages, so the above limitations and/or exclusions of liability may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

For more information about Tiger Electronics, our products and special promotions, please visit our Web Site at: [www.tiger toys.com](http://www.tiger toys.com)

**TIGER**  
ELECTRONICS, LTD.

© TM, & © 2000 Tiger Electronics, Ltd. All rights reserved.  
980 Woodlands Parkway, Vernon Hills, Illinois 60061, U.S.A.

© TM, & © 2000 Tiger Electronics UK Ltd. All rights reserved.  
Belvedere House, Victoria Avenue,  
Harrogate, North Yorkshire HG1 9EL United Kingdom  
[www.tiger toys.com](http://www.tiger toys.com)

© BANDAI 2000 MADE IN CHINA



PRINTED IN CHINA